



CountLab

USER'S MANUAL

Model 1 2 3

Visit CountLab.co.uk
to view all help videos

Product Features


Feature	CountLab 123
Cash drawer	Yes (small) Yes (large)
No. of departments	16
No. of PLUs	200
No. of clerks	8
No. of VAT rates (tax rates)	4
Type of payment	Cash, check, credit card
Cash register reports	X1/Z1 day's financial report X2/Z2 monthly financial report X/Z PLU report X/Z clerk report X/Z training report
Display	Numeric display (9-character LED)
Customer display	Yes
Printer Head	Thermal
Printer type	Single station roll printer
Printing speed (lines per second)	1.4
Paper width	57.5 ± 0.5 mm
Breakdown frequency (MCBF)	300,000 lines
Programmability	Date Time VAT rate (tax rate) Department PLU (item) -% rate Foreign currency Grand total & clear Z report Decimal point position (0. / 0.0 / 0.00 / 0.000) Time display(24-hour / 12-hour format) Date format (month-day-year / day-month-year) Clerk system active (yes / no) Compulsory to enter the clerk number for all transactions (yes / no)

INDEX


1 ECR Parts Description	01
2 Description To Ports	02
3 Load paper	03
4 Key Switch	04
4.1 Key switch positons	04
4.2 Keys	04
5 Keyboard	05
5.1 Changing the key labels	05
5.2 Keyboard description	05
6 Programming	08
6.1 Programming the date.....	08
6.2 Programming the time	08
6.3 Programming the VAT rate.....	08
6.4 Programming a percentage discount	09
6.5 Programming departments (DP)	09
6.5.1 Programming department status and fixed price	09
6.5.2 Printing the department programme	10
6.6 Programming the PLU (price look up).....	11
6.6.1 Programming the price and department assignment	11
6.6.2 Programming the PLU status and department assignment	11
6.6.3 Printing the PLUs programmed.....	12
6.7 Programming foreign currencies	13
6.8 System options.....	13
6.8.1 Programming system settings.....	13
6.8.2 Printing the system options (dump report)	16
7 Clerk System	17
7.1 Activating the clerk system.....	17
7.2 Clerk system without a password.....	17
7.2.1 Clerk log-on with clerk number.....	17
7.2.2 Clerk logs off	17
7.3 Clerk system with password.....	18
7.3.1 Programming a clerk password.....	18
7.3.2 Clerk log-on with clerk number and clerk password	18
7.3.3 Clerk logs off	19
8 Operation.....	19
8.1 Registering departments	19
8.2 Registering negative departments	20
8.3 Registering PLUs	21
8.3.1 Registering PLUs with a fixed price	21
8.3.2 Registering a PLU with free pricing.....	21
8.3.3 Registering negative PLUs.....	22

8.4 Concluding receipts / Methods of payment.....	22
8.4.1 Payment by cash.....	22
8.4.2 Payment by EC card / check.....	23
8.4.3 Payment by credit card / credit approval.....	23
8.5 Foreign currency payment.....	23
8.6 Registering a discount as an amount.....	24
8.7 Registering a discount as a percentage.....	24
8.7.1 Registering a percentage discount on a PLU	24
8.7.2 Registering a percentage discount on a subtotal.....	24
8.8 Error Correction and Void.....	24
8.8.1 EC	24
8.8.2 Normal void	25
8.9 Refund / Void.....	25
8.10 Received on account operations.....	25
8.11 Paid out operations	26
8.12 Printing function.....	27
8.13 Opening the cash drawer without a sale	27
8.14 Printing a receipt on/off	28
8.15 Printing a copy of the receipt.....	28
9 Training Mode.....	28
9.1 Activating Training mode.....	28
9.2 Practising in Training mode.....	28
9.3 Deactivating Training mode.....	29
10 Cash Register Reports	29
10.1 Basic information.....	29
10.2 Overview of cash register reports.....	29
11 Eliminating Problems.....	30
11.1 Error messages in the display	30
11.2 Display indicators	30
11.3 Printer malfunction	31
11.4 Resetting the cash register to its default settings.....	31

1 ECR Parts Description




- ① Receipt Printer
- ② ECR Body
- ③ Keyboard
- ④ Cash Drawer
- ⑤ Customer Display
- ⑥ Operator Display
- ⑦ Power Switch



2 Ports Description

Power port: power plug provided.

Cash Drawer Port: for cash drawer.



3 Load paper (Search for video CL200)

A




A.Open the printer cover in the arrow direction

B



B.Put in the paper roll.



C




C.Drag out the paper end and close the cover.Tear off the paper end out side the printer.

4 Key Switch


4.1 Key switch positions

The key can be turned to five different positions:




OFF

The cash register
is off




REG

Registration mode
Normal Sales Mode




X

Print report without
deleting report memory




Z

Print report
& reset memory
ready for next day



PRG

For Future Use



LOCK

Programming mode

4.2 Keys

Six different keys are available for use with the cash register:

Key identification	Switch position				
	LOCK	REG	X	Z	PRG
S	✓	✓	✓		
Z	✓	✓	✓	✓	
P	✓	✓	✓	✓	✓

5 Keyboard

In its standard form, the cash register leaves the factory with English labels on the keyboard.


It is possible to apply labels in different languages on the keys. Keyboard sheets in various languages are enclosed with the cash register for this purpose.

5.1 Changing the key labels










Proceed as follows:

1. Remove the transparent cap from the key.
If it is easier for you, carefully remove the entire key beforehand.
2. Replace the existing key label with a new label.
3. Replace the transparent cap back on the key.
If you removed the entire key, replace the key carefully back on the keyboard.

5.2 Keyboard description




KEY	Explanation
	Press and hold the FEED key to feed the receipt paper
	The RA key is used to record payments made into the cash register, such as a float. The total amount received on account is recorded in the financial report.
	The PO is used to record amounts removed from the cash drawer, such as paying a window. The total amount registered appears separately in the financial report.
	The EC (error correct) key is used to cancel an incorrect registration immediately after it has been entered. The error correct total is recorded in the financial report.
	The RETOUR/- or refund key is used to subtract an amount from the total amount of a sale. The financial report records the (-) key total. The RETOUR/- key is used for refund ansactions. The refund total is recorded in the financial report.
	The VOID key is used to complete the cancellation of an item within a registration which has not yet been concluded. The void total is recorded in the financial report.
	The Receipt ON/OFF key is used to switch of the receipt off or on.
	The X/TIME key is used to (multiply) entries for departments . e.g. 5 x £1.99
	The FC key is used for converting amounts into a foreign currency if used.
	The entry does not affect other sales totals or add upto a 7 digit number reference to a receipt. The #/NS key is used to open the cash drawer outside of a sale.
	The CARD key is used for transactions made with a credit card at the end of a sale to allocate payment by card
	The CLERK key is used to register a unique till operator (requires set up)
	The % - key is used to subtract a discount percentage from a item, sale or the total amount of a sale. The total amount registered by the % - key is recorded in the financial report.
	PLU (Price Look-Up) key. (only used if individual codes are used for products)
	The CHECK key is used at the end of the sale if payment is made by check.


KEY	Explanation
	This key is used to print a copy of the receipt or to print a receipt if turned off
<div> <div>789</div> <div>456</div> <div>123</div> <div>00.</div> </div>	<p>Numeric keys:</p> <p>The numeric keys are used to enter numbers.</p> <p>The  is used to enter the decimal point.</p> <p>The decimal is not used in daily use in the UK.</p>
<div> <div>DP 4DP 8DP 12DP 16</div> <div>DP 3DP 7DP 11DP 15</div> <div>DP 2DP 6DP 10DP 14</div> <div>DP 1DP 5DP 9DP 13</div> </div>	The Department keys are used to group items in a sale for reporting purposes.
	The  is used to delete all the entries made using the numeric keyboard or the  key before the entries have been finalised by pressing a department or function key.
	Press the  key to display the total amount of the sale adding up all the sale items.
	The  key is used for transactions made with cash.








6 Programming

6.1 Programming the date *(Search for video CL200)*

Example: 15 June 2010





- Set the key to PRG
- Enter the date as 6 digits (DDMMYY)
- Confirm by pressing 






Input	Display	Confirm by pressing
  	150610	
  		

6.2 Programming the time *(Search for video CL200)*

Example: 9:30 a.m.



- Set the key to PRG
- Enter the time as 4 digits (hhmm)
- Confirm by pressing 


Input	Display	Confirm by pressing
   	9.30	



6.3 Programming the VAT rate *(Search for video CL201)*









A maximum of four different VAT (Value Added Tax) rates can be programmed.

Note: On leaving the factory, the following value added tax rates are pre-programmed: TX 1 = 19% and TX 2 = 7%. If these rates correspond with those you need, no adjustments to the programme are necessary at this point.


Example 1: VAT rate 1 is 19%



- Set the key to PRG
- Enter the storage location (1, 2, 3 or 4)
- Confirm by pressing 
- Enter the VAT rate (to 3 decimal places but without a decimal point)
- Confirm by pressing 

Input	Display	Confirm by pressing
	0.01	
 		
  	19.000	

Example 2: VAT rate 2 is 7%




Refer to instructions in Example 1.

Input	Display	Confirm by pressing
2	0.02	SUB-TOTAL
7 0 0 0	7.000	CASH

6.4 Programming a percentage discount *(Search for video CL211)*

You can enter a discount value from 0.00 to 99.99%.

Example: 10% discount



- Set the key to PRG
- Enter the discount value as 4 -digits (10% = 1000).
- Confirm by pressing

Input	Display	Confirm by pressing
1 0 0 0	10.00	% -

6.5 Programming departments (DP) *(Search for video CL212)*

Eight departments can be programmed for the sixteen departments.

On leaving the factory, Departments 1 to 8 are already assigned VAT rate 1 at 19% and Departments 9 to 16 are assigned VAT rate 2 at 7%.

All the departments are set up as an itemised department with free pricing.

If these settings correspond with those you need, no adjustments to the programme are necessary at this point.

6.5.1 Programming department status and fixed price

Department status (3-digit)

1st digit

Itemised department	0
Single item department	1


2nd + 3rd digit

No VAT 00	00
VAT rate 1	01
VAT rate 2	02
VAT rate 3	03
VAT rate 4	04

Price entry

Free pricing	000
Fixed price	Enter the price with the number of decimal places


Example 1: DP1 should be set-up as an itemised department at VAT rate 1 (19%) and without a fixed price.



- Set the key to PRG
- Enter status S1 and S2 as 3 digits and confirm by pressing **CHECK**
- Enter fixed price or free pricing Assign the programmed settings to the department by pressing the corresponding DP key, in this case: **DP 1**

Input	Display	Confirm by pressing
0 0 1	0.01	CHECK
0 0 0	0.00	DP 1


Example 2: DP2 should be set-up as an itemised department at VAT rate 2 (7%) and with a fixed price of 5.00 £ (system option 1 in default setting: 2 decimal places).



- Set the key to PRG
- Enter status S1 and S2 as 3 digits and confirm by pressing **CHECK**
- Enter fixed price or free pricing Assign the programmed settings to the department by pressing the corresponding DP key, in this case: **DP 2**

Input	Display	Confirm by pressing
0 0 2	0.02	CHECK
5 0 0	5.00	DP 2

6.5.2 Printing the department program



- Set the key to PRG
- Press **8** 6 times
- Confirm by pressing **CASH**

Input	Display	Confirm by pressing
8 8 8	8888.88	CASH

Example printout:

***** SYSTE SETTING DUMP REPORT *****			
PRG	DEPARTMENT-01		
NAME			
PRICE	100.00		
TAX NO	01		
STATUS	00		
PRG	DEPARTMENT-02		
NAME			
PRICE	100.00		
TAX NO	01		
STATUS	00		

Department no. →

Fixed price →

Status →

← Tax rate

6.6 Programming the PLU (price look up) *(Search for video CL213)*


99 PLUs can be programmed for the 200 PLUs.

PLUs are programmed in two steps:

- Enter the price and department assignment for all PLUs.
- Enter the PLU status and department assignment for all PLUs.
(Not necessary if the PLU is operated with a fixed price.)

6.6.1 Programming the price and department assignment *(Search for video CL214)*

Example: PLU 12 must be priced at 2.50 € and is assigned to Department 1.



- Set the key to PRG
- Press **X/TIME**
- Enter the required PLU number
- Confirm by pressing **PLU**
- Enter the fixed price of the PLU and assignment it to the department required by pressing the relevant department key **DP 1**
- The next PLU automatically appears in the display.
- Proceed in the same way for the other PLUs.
- Conclude input by pressing **X/TIME**

Input	Display	Confirm by pressing
X/TIME	P001 0.00	
1 2	P 12 0.12	PLU
0 0 0	2.50	DP 1
	P 13 0.00	X/TIME


6.6.2 Programming the PLU status and department assignment

Note: This step is only necessary for PLUs which should also be able to operate with free pricing.

PLU status (1 digit)

Fixed price only 0
Also with free pricing 1


Example: In the case of PLU 12 (Department 1), free pricing is permitted.



- Set the key to PRG
- Press **PO**
- Enter the PLU number to be programmed
- Confirm by pressing **PLU**
- Enter the PLU status
- Confirm by pressing the relevant department key **DP 1**
- The next PLU automatically appears in the display.
- Proceed in the same way for the other PLUs.
- Conclude input by pressing **PO**

Input	Display	Confirm by pressing
PO	P001 0.00	
1 2	P 12 0.12	PLU
1	0.01	DP 1
	P 13 0.00	PO

6.6.3 Printing the PLUs programmed



- Set the key to PRG
- Press **PLU**

Input
PLU

Example printout:

```

*****
PLU DUMP REPORT
*****
PRG
PLU no. → PLU-001
NAME
PRICE      100.00
TAX NO     01
STATUS     00
LINK-DEPT  01

PRG
PLU-002
NAME
PRICE      100.00
TAX NO     01
STATUS     00
LINK-DEPT  02
    
```


6.7 Programming foreign currencies

A maximum of 4 foreign currencies can be programmed.

The following information must be entered for the programming process:

- Foreign currency identification (1, 2)
- Number of decimal places for the exchange rate (EXP): 0 to 8 decimal places are possible
- Decimal places for the foreign currency (DP): 0 to 3 decimal places are possible
- Exchange rate (RATE): 6-digit entry from 000001 to 999999

Example: Foreign currency no. 1: Euro to US Dollars (1 USD = 0.76494 EURO) as foreign currency no. 1



- Set the key to PRG
- Enter the foreign currency identification, here: 1
- Confirm by pressing
- Enter
 - EXP, here: 5
 - DP, here: 2
 - RATE, here: 076494
- Confirm by pressing


Input	Display	Confirm by pressing
1	0.01	FC
5 2 0 7 6 4 9 4	520764.94	CASH

6.8 System options (Search for video CL216)

The basic program settings of the cash register are stored in the system options.

6.8.1 Programming system settings

Example: Change the time display to the 12-hour format.



- Set the key to PRG
- Enter the system option number and status number (2 or 3 digits)
- Confirm by pressing


Input	Display	Confirm by pressing
4 1	41	RA

Note: The default settings appear in bold print.

System option	Status	Setting
1	0	Decimal point position: 0 (no point)
	1	Decimal point position: 0.0
	2	Decimal point position: 0.00
	3	Decimal point position: 0.000
2		(reserved)
3	1	Net price (exclusive of tax)
	2	Gross price (including tax)
4	0	Time: 24-hour format
	1	Time: 12-hour format
5	0	Print total taxable amount: No print
	1	Print total taxable amount: Print
6	0	Print net total for each tax rate: No print
	1	Print net total for each tax rate: Print
7	0	Date format: Month-Day-Year
	1	Date format: Day-Month-Year
8	0	Clerk system not active
	1	Clerk system active
9	0	Clerk log on not active after each transaction
	1	Clerk log on active after each transaction
10	0	Print extra line "Net Total": No print
	1	Print extra line "Net Total": Print
11	0	Zero skip printing for Z-report
	1	No zero skip printing for Z-report
12		(reserved)
		- Continued on next page -
13	0	No special European rounding Rounding occurs after pressing the SUB-TOTAL and CASH keys. If no special European rounding has been selected, rounding is performed according to commercial 5/4 rounding: If the first decimal place to be rounded is a 0, 1, 2, 3 or 4, the number is rounded down. If the first decimal place to be rounded is a 5, 6, 7, 8 or 9, the number is rounded up.
	1	European rounding: Switzerland 0.01 – 0.02 = 0.00 0.03 – 0.07 = 0.05 0.08 – 0.09 = 0.10

System option	Status	Setting
	2	European rounding: Sweden 0.00 – 0.24 = 0.00 0.25 – 0.74 = 0.50 0.75 – 0.99 = 1.00
	3	European rounding: Denmark 0.00 – 0.12 = 0.00 0.13 – 0.37 = 0.25 0.38 – 0.62 = 0.50 0.63 – 0.87 = 0.75 0.88 – 0.99 = 1.00
14	0	Printing of an additional bill permitted
	1	Printing of an additional bill not permitted
15	0	Z1 and Z2 counters are not deleted after Z-financial report printout
	1	Z1 and Z2 counters are deleted after Z-financial report printout
16	0	Grand Total is not deleted after Z1 financial report printout
	1	Grand Total is deleted after Z1 financial report printout
17	0	Grand Total is not printed on the financial report
	1	Grand Total is printed on the financial report
18	0	Receipt mode
	1	Journal mode (the winding reel is driven)
19	0	Basic currency is the local currency (amount ÷ conversion factor)
	1	Basic currency is foreign currency (amount × conversion factor)
20	0	Refunds are printed on the financial report
	1	Refunds are not printed on the financial report
21	0	Logo print on the receipt
	1	Logo no print on the receipt

6.8.2 Printing the system options (dump report)



- Set the key to PRG
- Press **9** 6 times
- Confirm by pressing

CASH

Input

9	9	9
9	9	9

Display

9999.99

Confirm by pressing

CASH


Example printout:

***** SYSTEM SETTING DUMP REPORT *****		
System Settings {	PRG	Status {
	SYSTEM NO.01 STATUS 2	
	SYSTEM NO.03 STATUS 2	
	SYSTEM NO.04 STATUS 0	
	SYSTEM NO.05 STATUS 0	
	SYSTEM NO.06 STATUS 0	
	SYSTEM NO.07 STATUS 0	
	SYSTEM NO.08 STATUS 1	
	SYSTEM NO.09 STATUS 0	
	SYSTEM NO.10 STATUS 0	
	SYSTEM NO.11 STATUS 1	
	SYSTEM NO.10 STATUS 1	
	SYSTEM NO.11 STATUS 0	
	SYSTEM NO.12 STATUS 0	
	SYSTEM NO.13 STATUS 0	
	SYSTEM NO.14 STATUS 0	
	SYSTEM NO.15 STATUS 1	
	SYSTEM NO.16 STATUS 0	
	SYSTEM NO.17 STATUS 0	
	SYSTEM NO.18 STATUS 0	
	SYSTEM NO.19 STATUS 0	
	SYSTEM NO.20 STATUS 0	
Tax retes {	DISCOUNT 0.00%	
	TAX—01 RATE 0.000	
	TAX—02 RATE 0.000	
	TAX—03 RATE 0.000	
Foreign currencies {	TAX—04 RATE 0.000	
	FC—01 RATE	
	FC—02 RATE	
Clerk passwork {	Z—REP SECU CODE	Z report password
	CLERK —01	
	NAME	
	SECU CODE	
	CLERK —02	
	NAME	
	SECU CODE	

7 Clerk System

The default setting for the clerk system is deactivated (refer to System Option 8).


7.1 Activating the clerk system *(Search for video CL221)*



- Set the key to PRG
- Press **8** and **1**
- Confirm by pressing **RA**

Input	Display	Confirm by pressing
8 1	0.87	RA

When the clerk system is activated, a dot appears in the display:



7.2 Clerk system without a password *(Search for video CL221)*


Condition: The clerk system is activated.

If no password has been programmed for a clerk, that clerk logs on at the cash register with his clerk number.

7.2.1 Clerk log-on with clerk number

Note: A maximum of 8 clerks can be registered in the system.

Example: Clerk no. 6 logs on.




- Set the key to REG
- Enter the 1-digit clerk number
- Confirm by pressing **CLERK**

Input	Display	Confirm by pressing
6	0.06	CLERK

7.2.2 Clerk logs off

Example: A salesperson logs off.



- Set the key to OFF

Note: System option 9 can be configured so that a clerk must log on again after each registration which is completed.


7.3 Clerk system with password *(Search for video CL222)*

It is possible to protect clerk log on codes by means of a password.

In this case, clerks log on by entering their respective clerk number and an additional password. The password is a 6-digit code. The clerk number and password thus comprise the 4-digit clerk code.

7.3.1 Programming a clerk password

Example: Programming the password for clerk no. 1 (password: 123456) and clerk no. 2 (password: 123456).



- Set the key to PRG
- Access the clerk password programming mode: press **4** 6 times
- Confirm by pressing **CASH**

Input	Display	Confirm by pressing
4 4 4	4444.44	CASH
4 4 4		CASH

Enter all the passwords in sequence (max. 8 passwords):

- Enter the 7-digit clerk code (1-digit clerk number and 6-digit password) and conclude by pressing **CLERK**


Input	Display	Confirm by pressing
1 1 2 3 4 5 6	11234.56	CLERK
1 1 2 3 4 5 6	11234.56	CLERK

- Exit from clerk password programming mode: press **CLEAR**


Note: If 000 is entered as the password for a clerk, the clerk system once again operates without a password for this clerk.

7.3.2 Clerk log-on with clerk number and clerk password

Structure of the clerk code



Example: Clerk no 1 logs on with password "145689" (clerk code: 145689).



- Set the key to REG
- Enter the 1-digit clerk number
- Enter the 6-digit clerk password
- Confirm by pressing

Input

1

Display

1456.89

Confirm by pressing


CLERK

Clerks remain logged on until they log off properly (see below).

Note: If an incorrect password is entered, error message "SEC Code" appears in the display.

7.3.3 Clerk logs off

Example: A salesperson logs off.




- Set the key to OFF

Note: System option 9 can be configured so that a clerk must log on again after each registration which is completed.

8 Operation

Set the key switch to REG for all operating processes.

Note: Incorrect input or error states (acoustic signal) can be cleared by pressing the CLEAR key.




8.1 Registering departments (Search for video CL231)

Always enter the price without a decimal point!

Note: The price may only contain a maximum of 7 digits.

Example 1: A PLU from department 1 with a value of 1.00 € must be registered.



- Enter the price
- Assign the department by pressing the relevant department key

Input


1 0 0

DP 1

DP 1

If the same PLU should be registered several times:

Example 2: A PLU from department 3€ with a value of 3.00 must be registered twice.



- Enter the quantity
- Confirm by pressing X/TIME
- Enter the price
- Assign the department by pressing the relevant department key

Note: The sum of Quantity x Price must not be greater than maximum capacity of the report memory!

Input

2

X/TIME


3 0 0

DP 3

8.2 Registering negative departments (Search for video CL231)

When a PLU is returned, initiate the negative registration by pressing the RETOUR/- key and register the returned PLU in the normal way.

Example 3: Two pieces of a PLU from department 3 with a value of 3.00€ are returned.



- Initiate registration of a negative department by pressing the RETOUR/- key.
- Register the PLU in the normal way.

Input

RETOUR/-

2

X/TIME

3 0 0

DP 3

Example receipt:

```

*****
YOUR RECEIPT
*****
CLERK#01
2.x      3.00
DEPT03   6.00
2.x      -3.00
DEPT03  -6.00
    
```

8.3 Registering PLUs *(Search for video CL213)*

Always enter the price without a decimal point!


Note: The price may only contain a maximum of 7 digits.

8.3.1 Registering PLUs with a fixed price

Condition: The PLU has been programmed with a fixed price.

Note: The PLU number may be a maximum of 3 digits.

Example 1: PLU no. 12 must be registered.




- Enter the PLU number
- Press the **PLU** key



If a PLU is being registered multiple times:

Example: PLU no. 12 registered twice.



- Enter the quantity
- Confirm by pressing **X/TIME**
- Enter the PLU number
- Press the **PLU** key




Note: The sum of Quantity x Price must not be greater than maximum capacity of the report memory!

8.3.2 Registering a PLU with free pricing


Condition: The PLU to be registered is programmed for free pricing.

Example 3: PLU no. 10 with a price of 2.49 € must be registered.



- Enter the PLU number
- Press the **PLU** key
- Enter the price
- Press the **PLU** key


Note: The sum of Quantity x Price must not be greater than maximum capacity of the report memory!




8.3.3 Refunding a PLU item sale *(Search for video CL234)*

When a PLU is returned, initiate the negative registration by pressing the **RETOUR/-** key and register the returned PLU in the normal way.

Example 4: PLU no. 10 with a price of 2.49 € is returned.



- Initiate registration of a negative department by pressing the **RETOUR/-** key.
- Register the PLU in the normal way.



Example receipt:

YOUR RECEIPT	


CLERK#01	
PLU10	2.49
PLU10	-2.49
SUBTOTAL	0.00
TOTAL	0.00
CASH	0.00

8.4 Concluding receipts / Methods of payment *(Search for video CL241)*


Note: Different methods of payment (tender media) cannot be used within one transaction!

A registration can only be concluded by one tender medium.


8.4.1 Payment by cash



- Press the **SUB-TOTAL** key to display and print the subtotal
- Enter the amount paid
- Conclude the receipt and print by pressing **CASH**




8.4.2 Payment by bank cheque




- Press the **SUB-TOTAL** key to display and print the subtotal
- Enter the amount paid
- Conclude the receipt and print by pressing

CHECK




8.4.3 Payment by credit card




- Press the **SUB-TOTAL** key to display and print the subtotal
- Enter the amount paid
- Conclude the receipt and print by pressing

CARD



8.5 Foreign currency payment

A customer pays a bill amounting to 15.- Euro with 20 US Dollars.



CLERK


- When all the PLUs have been registered, press the
- **SUB-TOTAL** key to produce the subtotal.

- Enter the foreign currency identification (here: US-Dollar =foreign currency identification 1) and press the
- **FC** key.

- Enter the amount received in the foreign currency and conclude the receipt. The change payable is displayed in the foreign currency.


- Then press the **FC** key to convert the change payable to the local currency.

Example: The customer receives either 30 Euro Cents or 39 US Cents change.




8.6 Registering a discount as an amount *(Search for video CL211)*

Example: A discount of 5,00 € is to be granted on a sale.



- Register the PLUs.
- Enter the amount granted as a discount.
- Press **RETOUR/-**.
- Continue with the registration.




8.7 Registering a discount as a percentage *(Search for video CL211)*

A percentage discount can be assigned to a single item registration or a subtotal.

8.7.1 Registering a percentage discount on a PLU

Example: A percentage discount of 5% is to be granted on a PLU.




- Register the PLU on which the percentage discount is to be assigned.
- Enter the percentage rate.
- Press **% -**.
- Continue with the registration.




8.7.2 Registering a percentage discount on a subtotal *(Search for video CL211)*

Example: A percentage discount of 7% is to be granted on a total sale.



- Register all the PLUs.
- Press the **SUB-TOTAL** key to produce the subtotal.
- Enter the percentage rate.
- Press **% -**.
- Conclude the registration by pressing **CASH**.



8.8 Error Correction and Void

Faulty registrations can be corrected immediately after entry or later in the transaction.


8.8.1 EC *(Search for video CL243)*

The last item entered during a registration can be corrected directly.

8.8.2 Normal void *(Search for video CL243)*

PLUs can be deleted as long as the registration has not yet been concluded.

Example: PLU no. 20 (fixed price item) has been registered and should be corrected immediately. However, more items have been registered in the meantime.



- Press **VOID**
- Register the PLU to be cancelled again.

Input



2


0



8.9 Refund / Void *(Search for video CL243)*

Registrations completed some time ago can be reverted as follows:

Example: PLU no. 50 (fixed price item) was purchased by a customer and later returned (refund).



- Press **RETOUR/-**
- Register the returned item again.
- Conclude the process by pressing the **CASH** key.

Input



5

0




(option)



8.10 Received on account operations *(Search for video CL246)*

Example: 10.00 € are paid in.



- Enter the amount paid into the cash register (max. 7 digits).
- Confirm by pressing

Input

1 0 00

Display


10.00

Confirm by pressing




RA

Example receipt:



8.11 Paid out operations *(Search for video CL247)*

Example: 5.00 € are paid out.



- Enter the amount removed from the cash register (max. 7 digits).
- Confirm by pressing PO

Input

5 00

Display


5.00

Confirm by pressing




PO

Example receipt:



8.12 Add a numeric reference to receipt *(Search for video CL251)*


A number containing up to 7 digits can be printed on the receipt, e.g. a customer number.
Example: The sequence of digits 1234567 should be printed on the receipt.



- Enter the number (max. 7 digits)
- Confirm by pressing #/NS
- Continue with the registration in the normal way.

Input	Display	Confirm by pressing
1 2 3 4	12345.67	#/NS
5 6 7		

Note: The entry does not influence the report memory.
Example receipt:



8.13 Opening the cash drawer without a sale *(Search for video CL252)*

Example: The cash drawer needs to be opened.



- Press #/NS

Input

#/NS

Note: The number of times the drawer is opened is recorded in the report memory and printed in the financial report.

Example receipt:



8.14 Printing a receipt on/off *(Search for video CL253)*



- Press Receipt ON/OFF

Input

Receipt ON/OFF

Note: If the print receipt function is switched off, a dot lights up in the display at the 2nd position.

8.15 Printing a copy of the receipt *(Search for video CL253)*

If the receipt printing function has been switched off via the Receipt ON/OFF key, a copy of the last receipt can be printed later.



- Press Receipt ISSUE


Input

Receipt ISSUE

9 Training Mode *(Search for video CL261)*

You can set the cash register to Training mode to practice using it without the registration processes and transactions being transferred to the report memory.

9.1 Activating Training mode




- Set the key to PRG
- Press 6 6 times
- Confirm by pressing CASH

Input	Display	Confirm by pressing
6 6 6	6666.66	CASH
6 6 6		

Note: If Training mode is activated, a dot lights up in the display at the 6th position.


9.2 Practising in Training mode



- Set the key to REG
- Practise operations using the cash register (refer to Chap. 10)

Note: No reports can be printed in Training mode.

9.3 Deactivating Training mode



- Set the key to PRG
- Press **5** 6 times
- Confirm by pressing **CASH**

Input	Display	Confirm by pressing
5 5 5	5555.55	CASH
5 5 5		

10 Cash Register Reports (Search for video CL262)



The cash register stores all the department or item-related sales transactions. Sums received on account, paid out, payments made in cash, by EC cards, on credit or in foreign currencies are stored and totalled. Similarly, opening the drawer for no sale requirements, refunds, discounts and corrections/voids are also stored. This data can be printed out in various ways in cash register reports.

10.1 Basic information

Cash register reports can be printed as X or Z-reports.

- X-reports are intermediate reports which can be printed out several times because the respective memory is not deleted after printing such reports. The key switch must be set to position X to print X-reports.
- Z-reports must be kept for the revenue authorities. When a Z-report is printed, the respective memory is deleted, which means that the grand total is reset to zero. Therefore, Z-reports can only be printed once. The key switch must be set to position Z to print Z-reports.

10.2 Overview of cash register reports



Type of report	Print by pressing
X1 Z1 Day's financial report	CASH
X Z PLU report, day	PLU
X Z Clerk report	CLERK

X2	Z2	Monthly financial report	9 9	CASH
X	Z	Training report	8 8	CASH

11 Eliminating Problems (Search for video CL263)
(Search for video CL264)


11.1 Error messages in the display

Error messages appear in the display in the case of incorrect operation.

Error message	Cause	Corrective measure
ϵ	Wrong key pressed.	Press CLEAR to clear error message. Then press the correct key.
SEC_ode	A password has been programmed for clerk log-on.	Press CLEAR to clear error message. Enter the 1-digit clerk number and 6-digit clerk password. Conclude by pressing CHECK .

11.2 Display indicators

The activation or deactivation of certain functions is indicated in the display by the respective dot.



Possible cause	Corrective measure
----------------	--------------------

11.3 Printer malfunction


In the event of a printer malfunction, switch off the cash register immediately and disconnect the power plug from the power socket.

Possible cause	Corrective measure
The paper roll is not inserted correctly. There is a foreign body in the printer mechanism.	Insert the paper roll again. Remove any foreign bodies. Attention: Remove the foreign body very carefully. Do not use a knife, screwdriver or anything similar. Never use force. This could damage the printer mechanism.

Switch the cash register on again and complete a registration. If the printer error continues to occur, contact the service centre.

11.4 Resetting the cash register to its default settings *(Search for video CL265)*

Attention: This operation resets the cash register to its default status and deletes all the programmed settings,cash register reports and report memories!



- Set the key to PRG
- Press
- Enter the following sequence of digits:
9 5 1 7
- Confirm by pressing

Input	Display	Confirm by pressing
<div><div>CLEAR</div></div>	<div><div>CLEAR</div></div>	
<div><div>9</div><div>5</div><div>1</div><div>7</div></div>	9517	<div><div>RA</div></div>
		<div><div>CLERK</div></div>